

# LabTecta® 66ST

Bearing Protector for Steam Turbines



## LabTecta®66ST — Bearing Protector for Steam Turbines



Process steam turbines present a unique challenge for bearing protection.

As the carbon rings containing the steam wear, high temperature / high velocity steam travels down the shaft directly at the bearing seal. Standard OEM labyrinth seals have proven to be ineffective preventing steam ingress.

**AESSEAL® has developed LabTecta®66ST designs specifically designed for steam turbine applications.**

This design features:


- High temperature static shaft seal
- Extra clearances for thermal expansion
- Steam deflector / Flinger
- TFE/P 'O' rings as standard
- Internal shut-off valve



For smaller steam turbines, the LabTecta-ST™ design provides excellent protection in a compact package. For larger steam turbines, the LabTecta-STAX™ provides easy installation with the capability to accommodate large axial shaft movement.

Standard designs are available for common steam turbines models like the Elliott® YR series. Specific designs can be manufactured at no additional charge.


Male Turbine Data



Manufacturer: ..... Model: .....

Seal Position: ☐ Drive End Outboard ☐ Drive End Inboard ☐ Gov. End Inboard


Female Turbine Data



Manufacturer: ..... Model: .....

Seal Position: ☐ Drive End Outboard ☐ Drive End Inboard ☐ Gov. End Inboard

## Press Fit / Flange Mount Turbine Data



Qty: .....

PCD: .....

Bolt Size: .....

Bolt Size: .....

Manufacturer: .....

Model: .....

Seal Position: ☐ Drive End Outboard

☐ Drive End Inboard

☐ Gov. End Inboard

### Machinery Application Details

Manufacturer: .....

Equipment Type: .....

Size / Model: .....

Industry: .....

Speed: ..... rpm Axial Movement (max) ..... Radial Movement (max) .....

### Description of Application

Bearing Type: Ball Bearing ☐

Sleeve Bearing ☐

Lubricant Type: Forced Lubrication ☐

Wet Slump ☐

Bearing Housing Temperature: ..... °C / ..... °F

Complete the information above and send to:

UK Fax: **+44 (0) 1709 720788** USA Fax: **+1 865 531 0571** E-mail: **sales@labtecta.com**

Further information about the AESSEAL® LabTecta®66 range is available in the standard LabTecta®66 brochure.

E-mail: **sales@labtecta.com** to request a copy or download it from our website: **www.labtecta.com**

This brochure is fully recyclable. When laminated, a sustainable, biodegradable and recyclable lamination is used.

For further information and safe operating limits contact our technical specialists at the locations below.



#### UK Sales & Technical advice:

AESSEAL plc  
Mill Close  
Bradmarsh Business Park  
Rotherham,  
S60 1BZ, UK  
Tel: +44 (0) 1709 369966  
E-mail: **enquiries@aes seal.info**  
**www.aes seal.com**

#### AESSEAL plc is certified to:

ISO 9001, ISO 14001, ISO/IEC 20000, ISO/IEC 27001,  
ISO/TS 29001, ISO 37001, ISO 45001 & ISO 50001



Net Zero champions globally



INVESTOR  
IN PEOPLE

Use double mechanical seals with hazardous products.

Always take safety precautions:

- Guard your equipment
- Wear protective clothing



#### USA Sales & Technical advice:

AESSEAL Inc.  
355 Dunavant Drive  
Rockford,  
TN. 37853,  
USA  
Tel: +1 865 531 0192  
E-mail: **usa@aes seal.com**  
**www.aes seal.com**

**Important:** Since the conditions and methods of use of this product are beyond our control, AESSEAL plc expressly disclaims any and all liability resulting or arising from any use of this product or reliance on any information contained in this document - AESSEAL plc standard conditions of sale apply. All sizes are subject to manufacturing tolerances. We reserve the right to modify specifications at any time. AESSEAL® is a Registered Trademark of AES Engineering Ltd, AESSEAL plc recognizes all trademarks and trademark names as the property of their owners.

LIT-UK/US-L-LabTecta-ST-08PDF Copyright © 2022 AESSEAL plc 06/2022